
Loudspeaker Flying Ball

Installation procedures:

1.First, please drill a 7-8mm round hole into the ceiling, and then insert the loudspeaker cable through the attached cover, which is for hiding the hole. Adjust the cable to an appropriate length (i.e. the height of the loudspeaker) and take it through the hole in the ceiling and then tie a knot to fix it. Press the cover to the end to set the loudspeaker.



2.Choose the required input voltage and output power for connection to the facility. As to the detailed specifications, they can be referred to the instruction on the loudspeaker itself and the following specifications of the product:

The connecting instruction for the product in use



Product specifications:

•	
Model	Pendant Sphere Loudspeaker
Build-in Speaker	A 5" full-range Paper speaker
Power Handling	Rated 20W/Max.40W
Loudspeaker Power	5W/10W/20W/8Ω
Input Impedance	(100V):2ΚΩ/1ΚΩ/500Ω
	$(70V)$:1K $\Omega/500\Omega/245\Omega$
	8Ω
Input Voltage	70V/100V
Frequency	110~13,000Hz (-10dB)
Output Sound Pressure & Voltage	92 dB(1W/M)
Dimension	ф 184*162.5mm
Weight	1.8Kg/3.97LBS





